




How to upgrade bios version?

1. Find the downloaded bios file.




2. Extract the zip file(Please choose to unzip in the C drive-USER path).







3. Click on View at the top of the menu bar and tick the File name extensions.



4. Press and hold the "win" + "X" keys on the keyboard and select Windows Terminal (Admin).



5. Type "f", then press the "Tab" key of the keyboard, f.bat appears and press and hold the enter key.



6. After the complete appears, the system will restart, indicating that it has been successful.

